


## Report Test

M/C : Henan Sanqiang Medical Equipment Liability Co. Ltd  
 Model : SQ-H220  
 Serial No : HNSQ2020050063

LOT No : 00979  
 Date : 22 May 2025

### Determination of Sterilization Operation Specification

Item Detail	Specification	Setting	Result
Chamber Setting Temperature	40.0-55.5 °C	45.0 °C	
Vacuum pressure	40-60 kPa	60 kPa	
Vacuum Time	50-60 min	60 min	
<b>Humidification</b>			
Humidity	50.0-90.0%	20.2 %	
<b>Sterilization</b>			
Sterilization Temperature	40.0-55.5 °C	43.5 °C	
<b>Gas Injection</b>			
Final pressure	0-10 kPa	4 kPa	
Final temperature of vaporizer	40.0-55.5 °C	44.8 °C	
<b>Exposure</b>			
Temperature at start point of Exposure time period	40.0-55.5 °C	43.3 °C	
Temperature at finish point of Exposure time period	40.0-55.5 °C	46.0 °C	
Exposure Time	120-240 min	180 min	
<b>Exhaust</b>			
Exhaust Time	60-80 min	75 min	
First Vacuum pressure	0-2 kPa	1.5 kPa	
Second Vacuum pressure	0-2 kPa	1.5 kPa	
Third Vacuum pressure	0-2 kPa	1.5 kPa	
Fourth Vacuum pressure	0-2 kPa	1.5 kPa	
Fifth Vacuum pressure	0-2 kPa	1.5 kPa	
<b>Storage</b>			
Storage Time	≥ 48 hour	≥ 48 hour	
<b>Chemical Test</b>			
EO sterilization temperature 40-55°C, Time Sterilization by EO 3hours	Blue	Red	Pass
<b>Biological Test</b>			
EZ Test Biological Indicator	Green	Green	Pass

  
 (.....)  
 Mr. Jutha Liam mukda

		LOT	Color	BOX	TOTAL / PCS
		206134			
1	Z-SCE9552	STERILE SURGICAL STEEL EAR STUDS PAIR - CROSS	LOT NO 00979		2
		206864			
9	Z-GPMBUSC62-1.2-8.0-3-CR	STERILE GOLD PVD COATED SURGICAL STEEL JEWELED FANCY CURVED MICRO BARBELL - TRIPLE GEM CURVE	LOT NO 00979		2
		205892			
1	Z-TBNDJ-1.6-12.0-5/8-HP-CR	STERILE TITANIUM DOUBLE JEWELED NAVEL BANANA	LOT NO 00979		50
2	Z-TMLBJ-1.2-10.0-3-HP-CR	STERILE TITANIUM PREMIUM CRYSTAL JEWELED MICRO LABRET	LOT NO 00979		100
		205925			
9	Z-EMJYB-1.2-3-AB	STERILE EPOXY COATED CRYSTALLINE JEWELED MICRO BALL	LOT NO 00979		5
10	Z-EMJYB-1.2-3-CR	STERILE EPOXY COATED CRYSTALLINE JEWELED MICRO BALL	LOT NO 00979		5
11	Z-GPTBMN-1.6-10.0-4-6	STERILE GOLD PVD COATED TITANIUM NAVEL BANANA	LOT NO 00979		4
12	Z-TBNDJ-1.6-10.0-5/8-HP-LR	STERILE TITANIUM DOUBLE JEWELED NAVEL BANANA	LOT NO 00979		10
13	Z-TBNDJ-1.6-10.0-5/8-HP-VI	STERILE TITANIUM DOUBLE PREMIUM CRYSTAL JEWELED NAVEL BANANA	LOT NO 00979		10
14	Z-TBNDJ-1.6-12.0-5/8-HP-AB	STERILE TITANIUM DOUBLE PREMIUM CRYSTAL JEWELED NAVEL BANANA	LOT NO 00979		6
15	Z-TBNDJ-1.6-10.0-5/8-HP-CR	TITANIUM INTERNALLY THREADED DOUBLE JEWELED NAVEL BANANA ATTACHMENT TOP - BOTTOM PRONG SET	LOT NO 00979		5
		205947			
42	Z-BKCOBC-0.8-10.0	STERILE BLACK PVD COATED SURGICAL STEEL SEAMLESS RING	LOT NO 00979		10
43	Z-BKCOBC-0.8-12.0	STERILE BLACK PVD COATED SURGICAL STEEL SEAMLESS RING	LOT NO 00979		10
44	Z-ZGCOBC-0.8-8.0	STERILE ZIRCON GOLD PVD COATED SURGICAL STEEL SEAMLESS RING	LOT NO 00979		10
45	Z-ZGCOBC-0.8-8.0	STERILE ZIRCON GOLD PVD COATED SURGICAL STEEL SEAMLESS RING	LOT NO 00979		10
		205961			
1	Z-GPBU-1.6-12.0-5/8-CR	STERILE GOLD PVD COATED SURGICAL STEEL PREMIUM CRYSTAL JEWELED NAVEL BANANA	LOT NO 00979		50
2	Z-SES14-CR	STERILE SURGICAL STEEL ROUND PRONG SET JEWELED EAR STUDS PAIR	LOT NO 00979		100
4	Z-TBNDJ-1.6-12.0-5/8-HP-CR	STERILE TITANIUM DOUBLE JEWELED NAVEL BANANA	LOT NO 00979		75
		2535603			
1	Z-RTA-6.0-70.0	STERILE DISPOSABLE MULTI ANGLED RECEIVING TUBE	LOT NO 00979		3288
		2535774			
3	THD-Z-GPMLJ200-1.6-CR	STERILE GOLD PVD COATED SURGICAL STEEL JEWELED ATTACHMENT FOR 1.6MM INTERNALLY THREADED PINS	LOT NO 00979		300
		2541686			
1	Z-GPIMLBJ-1.2-10.0-3-CR	STERILE GOLD PVD COATED SURGICAL STEEL INTERNALLY THREADED PREMIUM CRYSTAL JEWELED MICRO LABRET	LOT NO 00979		40
		2542393			
2	THD-Z-BKIMLBJ-1.2-8.0-3-CR	STERILE BLACK PVD COATED SURGICAL STEEL INTERNALLY THREADED PREMIUM CRYSTAL JEWELED MICRO LABRET	LOT NO 00979		100
10	THD-Z-GPMLB-1.2-6.0-3	STERILE GOLD PVD COATED SURGICAL STEEL MICRO LABRET FOR THENDRO	LOT NO 00979		150
23	THD-Z-TIMBN-1.2-8.0-3	STERILE TITANIUM INTERNALLY THREADED CURVED BARBELL FOR THENDRO	LOT NO 00979		250
		2542714			
2	TD-Z-BL-1.6-10.0-5	STERILE SURGICAL STEEL BARBELL FOR TDI	LOT NO 00979		100
		2543289			
4	PT-Z-GPTMBL-1.2-0.0-3	STERILE GOLD PVD COATED TITANIUM MICRO BARBELL	LOT NO 00979		150
		2543602			
1	PT-Z10-TMBH-1.2-10.0-3	STERILE TITANIUM MICRO CURVED BARBELL FOR PITT ROC	LOT NO 00979	SET/25	250
		2543723			
1	TD-Z-TBL-1.6-12.0-4	STERILE TITANIUM BARBELL FOR TDI	LOT NO 00979		300
		2542189			
6	SV-STERILIZE	SERVICE STERILE	LOT NO 00979		10
		2541131			
4	SV-STERILIZE	SERVICE STERILE	LOT NO 00979		19
		2543280			
3	SV-STERILIZE	SERVICE STERILE	LOT NO 00979		10
		2543376			
1	SV-STERILIZE	SERVICE STERILE	LOT NO 00979		10
		2540931			
1	SV-STERILIZE	SERVICE STERILE	LOT NO 00979		10
		2539029			
1	SV-STERILIZE	SERVICE STERILE	LOT NO 00979		10
					5469



Sterilization:  
Temperature: 45.7°C  
Humidity: 20.1RH  
Pressures: -1.0KPa  
Sterilization time: 3Hour  
Air replace rounds: 5  
round time: 15min(s)  
2025-5-22 13:47

Add E0 gas  
Temperature: 45.7°C  
Humidity: 20.2RH  
Pressures: -1.0KPa  
Sterilization time: 3Hour  
Air replace rounds: 5  
round time: 15min(s)  
2025-5-22 13:47

Evacuation  
Temperature: 44.4°C  
Humidity: 20.1RH  
Pressures: -0.0KPa  
Sterilization time: 3Hour  
Air replace rounds: 5  
round time: 15min(s)  
2025-5-22 13:30

Keeping Temp  
Temperature: 43.8°C  
Humidity: 20.1RH  
Pressures: -1.0KPa  
Sterilization time: 3Hour  
Air replace rounds: 5  
round time: 15min(s)  
2025-5-22 12:39

Keep pressure qualified  
Temperature: 42.7°C  
Humidity: 20.1RH  
Pressures: -0.0KPa  
Sterilization time: 3Hour  
Air replace rounds: 5  
round time: 15min(s)  
2025-5-22 12:37

Evacuation  
Temperature: 41.8°C  
Humidity: 20.2RH  
Pressures: -3.0KPa  
Sterilization time: 3Hour  
Air replace rounds: 5  
round time: 15min(s)  
2025-5-22 12:26

Heating up:  
Temperature: 23.6°C  
Humidity: 20.1RH  
Pressures: -3.0KPa  
Sterilization time: 3Hour  
Air replace rounds: 5  
round time: 15min(s)  
2025-5-22 11:51

Setting:  
Temperature: 45.0°C  
Humidity: 55.0RH  
Pressures: -0.0KPa  
Sterilization time: 3Hour  
Air replace rounds: 5  
round time: 15min(s)  
2025-5-22 11:50

22/05/2025  
LOT: 9791  
END

Air replacement:  
Temperature: 44.8°C  
Humidity: 20.2RH  
Pressures: -1.5KPa  
Sterilization time: 0Hour  
Air replace rounds: 1  
round time: 3min(s)  
2025-5-22 18:15

Air replacement:  
Temperature: 45.4°C  
Humidity: 20.1RH  
Pressures: -1.0KPa  
Sterilization time: 0Hour  
Air replace rounds: 2  
round time: 0min(s)  
2025-5-22 17:55

Air replacement:  
Temperature: 44.8°C  
Humidity: 20.2RH  
Pressures: -1.0KPa  
Sterilization time: 0Hour  
Air replace rounds: 3  
round time: 3min(s)  
2025-5-22 17:34

Air replacement:  
Temperature: 45.2°C  
Humidity: 20.2RH  
Pressures: -1.0KPa  
Sterilization time: 0Hour  
Air replace rounds: 4  
round time: 0min(s)  
2025-5-22 17:14

Air replacement:  
Temperature: 45.8°C  
Humidity: 20.2RH  
Pressures: -1.0KPa  
Sterilization time: 0Hour  
Air replace rounds: 5  
round time: 3min(s)  
2025-5-22 16:53

Sterilization:  
Temperature: 45.2°C  
Humidity: 20.2RH  
Pressures: -3.5KPa  
Sterilization time: 0Hour  
Air replace rounds: 5  
round time: 3min(s)  
2025-5-22 16:49

Sterilization:  
Temperature: 44.8°C  
Humidity: 20.1RH  
Pressures: -6.1KPa  
Sterilization time: 3Hour  
Air replace rounds: 5  
round time: 3min(s)  
2025-5-22 15:49