


Report Test

M/C: Henan Sanqiang Medical Equipment Liability Co. Ltd
 Model: SQ-H220
 Serial No: HNSQ2020050063

LOT No: 001145
 Date: 11 February 2026

Determination of Sterilization Operation Specification

Item Detail	Specification	Setting	Result
Chamber Setting Temperature	40.0-55.5 °C	45.0 °C	
Vacuum pressure	40-60 kPa	60 kPa	
Vacuum Time	50-60 min	60 min	
Humidification			
Humidity	50.0-90.0%	20.2 %	
Sterilization			
Sterilization Temperature	40.0-55.5 °C	43.5 °C	
Gas Injection			
Final pressure	0-10 kPa	4 kPa	
Final temperature of vaporizer	40.0-55.5 °C	44.8 °C	
Exposure			
Temperature at start point of Exposure time period	40.0-55.5 °C	43.3 °C	
Temperature at finish point of Exposure time period	40.0-55.5 °C	46.0 °C	
Exposure Time	120-240 min	180 min	
Exhaust			
Exhaust Time	60-80 min	75 min	
First Vacuum pressure	0-2 kPa	1.5 kPa	
Second Vacuum pressure	0-2 kPa	1.5 kPa	
Third Vacuum pressure	0-2 kPa	1.5 kPa	
Fourth Vacuum pressure	0-2 kPa	1.5 kPa	
Fifth Vacuum pressure	0-2 kPa	1.5 kPa	
Storage			
Storage Time	≥ 48 hour	≥ 48 hour	
Chemical Test			
EO sterilization temperature 40-55°C, Time Sterilization by EO 3hours	Blue	Red	Pass
Biological Test			
EZ Test Biological Indicator	Green	Green	Pass


 (.....)
 Mr. Jutha Liammukda
 Research and Development Engineer



FM-ISO0-009 Rev.02 (05/11/2020)

			LOT	Color	BOX	TOTAL / PCS
			218286			
1	Z-GPTMLBJ-1.2-10-0-3-CR	STERILE GOLD PVD COATED TITANIUM PREMIUM CRYSTAL JEWELLED MICRO LABRET	LOT NO 001145			20
			218343			
1	Z-TBNDJ-1.6-12.0-5/8-HP-CR	STERILE TITANIUM DOUBLE JEWELLED NAVEL BANANA	LOT NO 001145			15
2	Z-TBNDJ-OP-1.6-10-0-5/8-HP-CR	STERILE TITANIUM DOUBLE OPTIMA CRYSTAL JEWELLED NAVEL BANANA	LOT NO 001145			15
3	Z-TJNO-OP-1.0-6.5-2.35-HP-CR	STERILE TITANIUM OPTIMA CRYSTAL JEWELLED CURVED NOSE STUD	LOT NO 001145			15
4	Z-TMLBJ-1.2-8.0-3-HP-CR	STERILE TITANIUM MICRO LABRET WITH JEWELLED BALL	LOT NO 001145			20
5	Z-TFFIN-PIN-1.2-8.0-4B-HP	STERILE TITANIUM THREADLESS LABRET PIN	LOT NO 001145			15
			217662			
3	Z-GPBCSH-0.8-8.0	GOLD PVD COATED SURGICAL STEEL HINGED SEGMENT RING PLAIN POLISHED	LOT NO 001145			50
			2586436			
4	Z-SCES386	STERILE SURGICAL STEEL EAR STUDS PAIR - STAR	LOT NO 001145			10
			2586458			
4	PT-2-GPTBNJ-1.6-10-0-5/8-CR	STERILE GOLD PVD COATED TITANIUM PREMIUM CRYSTAL JEWELLED NAVEL BANANA	LOT NO 001145			100
			2570180			
1	PT-2-GPTBL-1.6-14-0-5	STERILE GOLD PVD COATED TITANIUM BARBELL	LOT NO 001145			50
19	PT-2-XJNO2-0.8-6.0-2.35-CL-CR	STERILE BIOFLEX JEWELLED CURVED NOSE STUD FOR PTTT ROC	LOT NO 001145			100
			2570517			
1	THD-Z-SPBC-1.6-10-0-4	STERILE GOLD PVD COATED SURGICAL STEEL BALL CLOSURE RING FOR THENDRO	LOT NO 001145			100
			2670897			
1	Z-GPBL-1.6-19-0-5	STERILE GOLD PVD COATED SURGICAL STEEL BARBELL	LOT NO 001145			50
			2571520			
1	Z-G18TMLB-1.2-10-0-3	STERILE GOLD PVD 18K COATED TITANIUM MICRO LABRET	LOT NO 001145			20
			2571590			
1	Z-LJNO-1.0-6.0-2.35-CR	STERILE SURGICAL STEEL PREMIUM CRYSTAL JEWELLED LARGE LEFT CURVE NOSE STUD	LOT NO 001145			20
			2671756			
9	PT-2-INP-1.2-50-0	STERILE SURGICAL STEEL INTERNALLY THREADED INSERTION PINS FOR PTTT ROC	LOT NO 001145			100
						790

Sterilization:
Temperature: 44.83t
Humidity:20.19H
Pressure:-4.00Pa
Sterilization time:3Hour
Air replace rounds:5
round time:15min(s)
2026-2-11 13:38

Add ED gas
Temperature: 44.74t
Humidity:20.19H
Pressure:-4.00Pa
Sterilization time:3Hour
Air replace rounds:5
round time:15min(s)
2026-2-11 13:38

Evacuation
Temperature: 44.24t
Humidity:20.19H
Pressure:-0.00Pa
Sterilization time:3Hour
Air replace rounds:5
round time:15min(s)
2026-2-11 13:33

Keeping Two
Temperature: 42.74t
Humidity:20.19H
Pressure:-1.00Pa
Sterilization time:3Hour
Air replace rounds:5
round time:15min(s)
2026-2-11 12:33

Keep pressure qualified
Temperature: 41.34t
Humidity:20.19H
Pressure:-0.00Pa
Sterilization time:3Hour
Air replace rounds:5
round time:15min(s)
2026-2-11 12:33

Evacuation
Temperature: 41.44t
Humidity:20.19H
Pressure:-3.00Pa
Sterilization time:3Hour
Air replace rounds:5
round time:15min(s)
2026-2-11 12:20

Heating:40t
Temperature: 22.44t
Humidity:20.19H
Pressure: 3.00Pa
Sterilization time:3Hour
Air replace rounds:5
round time:15min(s)
2026-2-11 11:38

Setting:
Temperature: 46.04t
Humidity:20.19H
Pressure:-0.00Pa
Sterilization time:3Hour
Air replace rounds:5
round time:15min(s)
2026-2-11 11:38

11/02/26
Lot 1145

END
Air replacement:
Temperature: 45.14t
Humidity:20.19H
Pressure:-1.00Pa
Sterilization time:3Hour
Air replace rounds:1
round time:15min(s)
2026-2-11 16:2

Air replacement:
Temperature: 45.04t
Humidity:20.19H
Pressure:-1.00Pa
Sterilization time:3Hour
Air replace rounds:2
round time:15min(s)
2026-2-11 17:45

Air replacement:
Temperature: 45.24t
Humidity:20.19H
Pressure:-1.00Pa
Sterilization time:3Hour
Air replace rounds:3
round time:15min(s)
2026-2-11 17:25

Air replacement:
Temperature: 45.04t
Humidity:20.19H
Pressure:-1.00Pa
Sterilization time:3Hour
Air replace rounds:4
round time:15min(s)
2026-2-11 17:15

Air replacement:
Temperature: 45.24t
Humidity:20.19H
Pressure:-1.00Pa
Sterilization time:3Hour
Air replace rounds:5
round time:15min(s)
2026-2-11 16:44

Sterilization:
Temperature: 45.24t
Humidity:20.19H
Pressure:-0.00Pa
Sterilization time:3Hour
Air replace rounds:5
round time:15min(s)
2026-2-11 16:38

Sterilization:
Temperature: 44.34t
Humidity:20.19H
Pressure:-2.00Pa
Sterilization time:3Hour
Air replace rounds:5
round time:15min(s)
2026-2-11 13:40